

Planter Options



Custom-Built Modular High/Low Operator's Platforms for Drawn Toolbars

Provides optional personnel carrier configurations with walkway, handrails and plug-in style side steps for safe mounting and dismounting. Includes lift-off design for seed packet holders and personnel carriers. Similar modular high/low operator's platforms are also available for mounted planters.




Optional Boerner Double Divider System

is designed using gravity to gently divide the seed from each seed packet reducing the number of operators needed.



Electric Seed Tray Indexer

eliminates the need for seed packets. Pre-fill specially designed seed trays for each plot. The trays are fed through the indexer automatically releasing the seed to each row of each plot. Ideal application for planting short plots or micro plots.



Notched Row Marker Blades with Hubs and Weights for minimum or no-till applications.

Transmission Options

- ALMACO Flat Plate Transmission with 50 combinations to accommodate seed spacing and population requirements; changes can be made in seconds without the use of any tools
- Twin Plate Hydraulic Drive Transmission:
 - Allows population settings from the control box
 - Eliminates manually changing sprockets from different population settings
 - Infinite transmission settings
 - Allows pre-programming to change populations on-the-go
- Zeromax transmission



Slave drive tire design reduces the risk of dirt and trash getting into the planter drive chain.